

Contents

Fixed Displacement Vane Pumps

Series P2/P3 Variable Volume Piston Pumps

Introduction	A4
Specifications	A5
P2 cut-away	A6
Installation Series P2 Side Ports	A7
Installation Series P2 Rear Ports	A8
Installation Series P3	A9
Ordering Information	A10

Variable Volume Piston Pumps

Series PAVC

Introduction	A11 - A14
Control Options	A15 - A20
Series PAVC33/38	A21 - A28
Series PAVC65	A29 - A35
Series PAVC100	A36 - A45
Installation Information	A46 - A49, A54
Technical Information	A50 - A53

Series PVP

Introduction	A59 - A60
Control Options	A61 - A67
Series PVP 16	A68 - A77
Series PVP 23/33	A78 - A87
Series PVP 41/48	A88 - A99
Series PVP 60/76	A100 - A109
Series PVP 100/140	A110 - A119
Installation Information	A120 - A122

Series PHP 10

Technical Information	A123 - A127
Ordering Information	A128

Series PHP 40

Technical Information	A130 - A134
Ordering Information	A135

Series PHP 60

Technical Information	A138 - A142
Ordering Information	A143

Electrohydraulic Accessories for PVV & PAVC Pumps

Introduction	A146
Technical Information	A147 - A151
Installation Information	A152 - A156



